Install pole and then
clamps , slide pole out
and place bars level with
clamps to thread